



Installation Instructions

Step #1

Install full bead of Polyfoam adhesive on roof underlayment



Step #2

Set and position TOP NOTCH into Polyfoam Adhesive



Step #3

Install Polyfoam adhesive to top side of TOP NOTCH



Step #4

Install ridge roof tile